Programming Your Remote Control to your Set Top Box and TV

Amino (140, 540)

IS-5112W and IS-5041

ADB

Kamai 7

Program the Remote to Your STB & TV

Backlit Remote

1 Press STB

2 Press and Hold SETUP until STB blinks twice

3 Enter the STB code:

Amino	1898
ADB	2254
Innovative (IS)	1376
Kamai	4437

STB will blink twice to confirm the code is stored

---

1 Power the TV on

2 Press TV

3 Press and Hold SETUP until the TV key blinks twice

4 Enter 9 9 1

5 Press and release CH+ until the TV powers off

6 Press SETUP to save the code

Follow the remote programming instructions for master power on side 2 to continue.

Program the Remote to Your STB & TV

Royal Remote

1 Press CABLE POWER

2 Hold SET UP, plus the colored hotkey, until CABLE POWER blinks twice

Colored Hot Keys:

Amino 140/540	Yellow (A)
Innovative (IS) 5112/5041	Blue (B)
ADB 3800/3721	Red (C)
Kamai 7	Green (D)

---

1 Power the TV on

2 Press and hold SET UP until CABLE POWER blinks twice

3 Press TV POWER

4 Press and Hold OK until the TV shuts off, release OK

(May take up to one minute and the CABLE POWER key will flash)

Programming Your Remote Control to your Set Top Box and TV

Program the Master Power Control

Backlit Remote Only

This eliminates the need to press the “STB” and “TV” when turning on the TV.

1 Make sure the TV is on

2 Press STB

3 Press and hold SETUP, STB will blink twice

4 Press 9 9 5, STB will blink twice

5 Press POWER

6 Press TV

7 Press STB

8 Press and hold SETUP, until STB blinks twice

Backlit Remote

Step-by-Step Guide to Programming Your New Remote

The Big Button remote control is already pre-programmed to control Amino Set Top Boxes (STB), shown here:

Amino

If you have an Amino STB, skip the instructions on this page and proceed with both sets of instructions on the back side of this page. This process must be done for every STB in your home.

If you have any of the ADB Set Top Boxes shown below, you will have to reprogram the remote control using the insructions on this page. Repeat process for every ADB STB in your home.

ADB 3800

ADB 3721

ADB 5721

1. Press the **STB** button **and** the **OK/SEL** button simultaneously for 3 seconds.

2. Press **2 5 9**. The STB button will blink twice.

3. Press the **STB** button to save.

TV
Select the Device to operate.

Menu
Displays the menu.

Arrow Keys
Navigate choices.

Guide

Page +/-
Page up or down in lists and Interactive Program Guide.

Volume Control

Mute
Turn sound on or off.

Favorite
View favorite channels.

Number Pad
Select channel or enter PIN.

Aspect Ratio
Temporarily change the conversion mode from Original Size to Fit To Screen.

OFF
Turn on/off a selected device.

STB
Select the Device to operate.

Information

OK/SEL
Choose the highlighted option.

Exit
Return to previous screen.

Red, Green, Yellow, Blue
Access additional features.

Channel Navigation

On Demand
Access video on demand.

Last

Input
Change the input selection on your TV.

1 Program the Remote to Your TV

1. Make sure the **TV** is on.
2. Press and hold the **TV** key **AND** the **OK/SEL** key for 3 seconds - the **TV** key will stay lit.
3. Press and hold **Ch↑** key until the TV powers off.
4. Release the **CH↑** key and press the **TV** key to save the code.

Big Button

2 Program the Master Power Control

This eliminates the need to press the "STB" and "TV" buttons when turning on the TV.

1. Make sure the TV is on.
2. Press **STB**.
3. Press and hold the **OFF** key **AND** the **OK/SEL** key for 3 seconds.
4. Press **STB**.
5. Press **OFF**.
6. Press **TV**.
7. Press **OFF**.
8. Press and hold **Ch↑** to save command - STB key will blink twice.

Program the Remote to Your Other Devices (AUD, DVD, VCR)

The AUD, DVD and VCR mode keys have a default setting which means they are automatically set to the STB. If you would like to program these mode keys to your devices, please follow the instructions below to lock the default setting.

1. Press and Hold **SETUP**, until the mode key blinks twice.

2. Type **9-9-2**.

3. Press the **mode** key, AUD, DVD or VCR you desire to program, twice.

4. This will remove the STB mode and a new Audio, DVD or VCR code can now be programmed.

5. Manually turn ON the device that you want to setup on the remote.

6. Press and release the **mode** key for the device you are programming, it will blink once.

7. Press and Hold **SETUP**, until the mode key blinks twice.

8. Press and release the **mode** key. The mode key will stay lit.

9. Find your AUD, DVC or VCR device brand for the chart (contact NDTC) and note the DIGIT key assigned to your brand. Press and hold down the DIGIT key for your device/brand while pointing the remote to the device.

10. Let go of the key when your device turns OFF. Setup for that device is complete.

Programming the Remote for Your STB

1. Turn on TV
2. Press **CBL** button
3. Press and hold **SETUP** and one of the colored buttons simultaneously (**CBL** will blink twice)
   - **Blue** button = Amino Kamai
   - **Red** button = Amino
   - **Green** button = Innovative Systems
   - **Yellow** button = ADB
4. Test to see if it works

Programming the Remote for Your TV

Set Up Remote for TV: (code search method) 2-Parts

PART 1

1. Turn on TV
2. Press **TV** key
3. Hold down **SETUP** (TV key will blink twice)
4. Press **9, 7, 2, Ch+** (TV key will blink twice)

PART 2

1. Press **TV** key
2. Hold down **SETUP** (TV key will blink twice)
3. Press **9, 9, 1** (TV key will blink twice)
4. Press **"CH+" over and over until TV turns off** ; (if you go too far, back up by pressing "**CH-**")
6. Press **SETUP** to store the code
7. Test by pressing **TV** key to turn TV back on

Set Up Remote for TV: (Using existing codes)

1. Turn on TV
2. Find TV Code (found in Remote Control User's Guide)
3. Press **TV** Key
4. Hold down **SETUP** (TV key will blink twice)
5. Enter TV Code (TV key will blink twice)
6. Press **TV** (TV should turn off if it's the correct code)
7. Repeat steps 3-6 if TV does not turn off until correct code is found

NDTC™

STREAM. SURF. CONNECT.