

# Step-by-Step Guide to Programming Your New Remote

The backlit remote control is already pre-programmed to control Amino Set Top Boxes (STB), shown here:

Amino



If you have an Amino STB, skip the instructions on this page and proceed with both sets of instructions on the back side of this page. This process must be done for every STB in your home.

If you have any of the ADB Set Top Boxes shown below, you will have to reprogram the remote control using the instructions on this page. Repeat process for every ADB STB in your home.

ADB 3800




ADB 3721



ADB 5721



1. Press the **STB** button to choose the STB function.
2. Press and Hold **Setup** until the STB key blinks twice.
3. Press **2254**.
4. The STB button will blink twice, indicating successful programming.
5. Follow the remote programming instructions on page 2 to continue.



# 1

## Program the Remote to Your TV

1. Make sure the **TV** is on.
2. Press **TV**, it will blink once.
3. Press and hold **SETUP**, the TV key will blink twice.
4. Press **9-9-1**, the TV key will blink once.
5. Press and release the **CH+** key continuously, then stop when the TV turns off.
6. Press **SETUP** to save code.



# 2

## Program the Master Power Control

This eliminates the need to press the “STB” and “TV” buttons when turning on the TV.

1. Make sure the TV is on.
2. Press **STB**.
3. Press and hold **SETUP**, the STB key will blink twice.
4. Press **9-9-5**, the STB key will blink twice.
5. Press **POWER**.
6. Press **TV**.
7. Press **STB**.
8. Press and hold **SETUP**, until the STB key blinks twice.